



Data Logger Wifi Stick Quick User Guide

DLS Version: 2.0




Delivery Content

- 1 pc WiFi
- 1 pc WiFi external antenna
- 1 pc Data Logger Wifi Stick Quick User Guide

Introduction

Data Logger Wifi Stick is mainly used in inverters to realize simple and quick access to Internet. Users can easily check device information by logging in the monitoring center. The communication topology is as shown below:



Description of Symbols
To ensure normal use of the datalogger, before using the datalogger, be sure that:

- The connected wireless router can normally access to Internet;
- The communication address of the inverter MUST BE "01", which is default value.
- A WiFi-enabled mobile phone is connected to this device for parameter setting.

1 Electrical Connection

Connect WiFi to the corresponding interface on the inverter. Solis-1P5K-4G is used as an example in this manual. Please perform relevant operations as indicated below:





NOTES
The datalogger must be kept away from large metal objects and electrical devices with strong magnetic fields, such as microwave oven, refrigerator, cordless phone, concrete wall, PV panel and metal wall, to ensure the communication quality. Communication quality may be affected in lightning storms.

2 Create Solis monitoring account

Step 1: Mobile phone scan the QR code to download the APP, or in the APP Store or Google Play search Ginlong Home or Ginlong Pro. Or click the "+" in the upper right corner.





Step 2: Click on the "Register".







3 Create plant

Step 1: In the APP homepage and click "Build Your Plant Within 1 Minute!" in the middle of the screen. Or click the "+" in the upper right corner.




4 Configure WiFi

Step 1: Click the "Connect" on the Device interface.




5 Distributor/Installer create plant

In order to facilitate registration, you can also let the distributor/installer register the plant, then Link it to you. Click [] at the far right of the bottom of the screen and tell your Distributor/installer "ID" below the nickname to build the plant for them. (Note: your Distributor/installer must have a Ginlong Pro account)





Step 1: Select the plant and enter Intro. Click the "installer" or "distributor".





6 Link distributor/installer


Step 1: Enter the company name of the installer or distributor. Then click the "Search".



Step 2: Enter the SN of the datalogger. The datalogger SN can be automatically scanned by placing the purchased device barcode in the scan box. If you can't scan, you can also manually enter the datalogger SN (just enter the digital serial number).





Step 3: Click your installer/distributor to view the details of the installer/distributor. After confirming the information, click [Bind Distributor/Installer] and the plant will appear in the monitoring interface of the designated installer/distributor. (note: your installer/distributor must have a Ginlong Pro account to appear in the search list)




7 Distributor/Installer create plant


Step 1: Enter the company name of the installer or distributor. Then click the "Search".



Step 2: Enter the SN of the datalogger. The datalogger SN can be automatically scanned by placing the purchased device barcode in the scan box. If you can't scan, you can also manually enter the datalogger SN (just enter the digital serial number).



Step 3: Click your installer/distributor to view the details of the installer/distributor. After confirming the information, click [Bind Distributor/Installer] and the plant will appear in the monitoring interface of the designated installer/distributor. (note: your installer/distributor must have a Ginlong Pro account to appear in the search list)



8 Contact

If you have any technical questions about our products, please contact us. Before contacting us, please confirm the following items:

- Equipment model
- Serial number of the datalogger
- Problem description
- Screenshot of the Status page in the configuration interface

Ningbo Ginlong Technologies Co., Ltd.
No. 57 Jintong Road, Binhai Industrial Park, Xiangshan, Ningbo, Zhejiang, 315712, P.R.China.
Tel: +86 (0)574 6578 1806
Fax: +86 (0)574 6578 1606
Email : info@ginlong.com
Web : www.ginlong.com

Tip: if you cannot connect to WiFi, try the following.

- If the signal strength of the selected network is <15%, the connection is unstable, please adjust the router's antenna position or increase the relay.
- The router's SSID and password do not use!@#\$%&*~'(){}? and other special characters.
- Some enterprises may limit the WiFi connection, so it is recommended closing limit function of the Qos.
- Support the normal routing encryption (WEP/WPA2PSK WPA2PSK), does not support mixed multiple encryption methods.
- Open the router's DHCP function, otherwise unable to connect to router wifi.

Tip: If configuration failure, there may be the following reasons:

- If the signal strength of the selected network is less than 15%, the connection is unstable. Please adjust the position of the router's antenna or increase the relay.
- Connect to other network accounts with Wifi, but not this time.
- The serial number cannot be scanned, and it is wrong to input the serial number manually.
- 5G WiFi is not supported.